

## **INSTALLATION MANUAL**

Room thermostat

EKRTR EKRTETS













Read this manual attentively before starting up the unit. Do not throw it away. Keep it in your files for future reference.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information.

## Contents

1. Introduction	2
2. Installation of EKRTETS as floor temperature sensor	3
3. Installation of EKRTR	5
4. Setting up codes in the installer menu	12
5. Technical characteristics	20

## **1.** Introduction

The room thermostat EKRTR can be used to control floor heating-cooling applications and floor heating/cooling applications.

It is typically connected to the indoor unit. Refer to the "Typical application examples" in the Installation manual of the indoor unit.

- In case of floor heating-only applications the room thermostat can also be connected to the individual motorized valve of the floor heating loop.
- If a floor heating-only application is used in combination with fan coil units each fan coil unit should have its dedicated fan coil thermostat.

Optionally, an external temperature sensor EKRTETS can be connected to the thermostat and used as:

- external ambient temperature sensor to control the room temperature (instead of the temperature sensor inside the thermostat). In that case, install the temperature sensor where you want to control the ambient temperature.
- floor temperature sensor to protect the floor temperature. In that case, install the temperature sensor in the floor (refer to "Installation of EKRTETS as floor temperature sensor" on page 3).

2

## 2. Installation of EKRTETS as floor temperature sensor

As it should be integrated into the floor, the installation of the temperature sensor EKRTETS should be planned and performed in advance.

If EKRTETS is installed as floor temperature sensor, the thermostat EKRTR should be wall-mounted. Refer to "Wall-mounted installation" on page 5.



The below procedure only serves as an example. Your actual situation may differ from what is represented here.

1 Take the installation suggestions for the thermostat into account when selecting the installation location. Refer to figure 3.



2 Integrate the EKRTETS temperature sensor in an electrical conduit (Ø16 mm maximum) in the floor construction as shown below.

Make sure to seal the temperature sensor electrical conduit to protect the thermostat from hot air currents and to allow the replacement of the temperature sensor.



- 1 Thermostat
- 2 Temperature sensor conduit (Ø16 mm maximum)
- 3 Temperature sensor EKRTETS (in conduit with seal)
- 4 Water pipes
- **3** Pass the temperature sensor cable through the conduit until it reaches the seal.
- 4 Connect the temperature sensor cable to the thermostat as described in "Wall-mounted installation" on page 5.



Install the temperature sensor as close as possible to the floor loop inlet.

## 3. Installation of EKRTR

You can mount the EKRTR thermostat on the wall or use it as table-top model.

#### 3.1. Wall-mounted installation

The EKRTR thermostat can be wall-mounted, with supplied screws and plugs. Refer to figure 1.

This is the case when you want to install the optional EKRTETS as external temperature sensor.

- 1 At the left of the thermostat, gently push the lid.
- 2 Remove the front cover by pulling it towards you.
- 3 Optionally for the EKRTETS, unscrew the screw of the cable holder in the bottom left corner of the back part of the thermostat and remove the transparent cable protection.
- 4 Remove the battery insulator.



5 Drill holes in the wall taking the dimensions of the thermostat into account and insert the supplied plugs in the holes. Refer to figure 4 (unit of measurement: mm). 6 Optionally, pass the temperature sensor wiring (EKRTETS) through the back of the thermostat and wire it as shown below.



7 Fasten the thermostat with the supplied screws.



Be careful not to pinch the wiring when fastening.

- 8 Optionally for the EKRTETS, put the transparent cable protection back into place and fix the cable protection with the screw.
- 9 Close the thermostat cover.
- 10 Remove the protective film from the LCD.

#### 3.2. Table-top installation of the thermostat

Only if the optional temperature sensor EKRTETS is not installed as external temperature sensor, the EKRTR can be used as a table-top model.

In that case, no particular installation for the thermostat is needed. The thermostat functions as a complete wireless unit and can be put anywhere in the house into its table holder.



Remove the battery insulator and the protective film from the LCD, as described in "Wall-mounted installation" on page 5.

#### 3.3. Installation of the receiver

Typically the receiver needs to be installed next to the altherma<sup>°</sup> by **DAIKIN** indoor unit.



Before obtaining access to terminals, all power supply circuits must be interrupted.

Keep the front clear at all times for access.

- 1 Drill holes in the wall taking the dimensions of the receiver into account and insert the supplied plugs in the holes. Refer to figure 5.
- 2 Fasten the receiver with the supplied screws.
- 3 Unscrew both screws and remove the front cover.



4 Unscrew both screws of the lower right cable bracket and remove the bracket.

- 5 According your application, perform the wiring.
- 5a When connected to the indoor unit, wire the indoor unit and the receiver as shown below.



н	Heating demand
С	Cooling demand

For heating-only applications, wire 17-C or 2-C is not to be installed.

Use wire size 0.75~1.50 mm<sup>2</sup>.

5b When connected to the motorized valve, wire the motorized valve and the receiver as shown below (for heating-only applications).



The output relays (H and C are voltage-free contacts) can handle a maximum load of 100 mA - 230 VAC.



Make sure to protect the power supply with a fuse of 3 A.

Select the power cable in accordance with relevant local and national regulations.

A main switch or other means for disconnection, having a contact separation in all poles, must be incorporated in the fixed wiring in accordance with relevant local and national legislation.

- 6 Put the cable bracket back into place and tighten the screws.
- 7 Close the receiver cover and tighten the screws.

#### Receiver-thermostat radio configuration

You need to configure the radio connection between the receiver and the thermostat in order to make communication possible.

 Put the receiver in radio configuration mode by pressing during 4 seconds.
The <sup>2</sup>/<sub>2</sub> L ED lights up group and the receiver is new waiting for

The  $\tilde{i}$  LED lights up green and the receiver is now waiting for a thermostat configuration address.

If needed, you can simply exit this mode by pressing  $\textcircled{\sc 0}$  again.

2 Send the configuration address by going to code 5r B3 (rF in k) in the installer menu on the thermostat.

Refer to "Setting up codes in the installer menu" on page 12. The thermostat will now send radio signals. On the LCD the icon  $(\mathfrak{h})$  flashes.

**3** Verify that the radio signals are correctly received by the receiver.

If the configuration is OK, the  $\widehat{\widehat{i}}$  LED blinks green at each radio signal received from the thermostat.

This also means that the receiver has left the radio configuration mode.

- 4 On the thermostat, exit the installer menu by pressing b till the "End" code is displayed and then pressing @@.
- 5 Verify if the receiver is in thermostat mode and not in manual mode by checking if the <sup>®</sup> LED is off.

Refer to "LED overview" on page 10.

#### LED overview

٢	~_	(:	Meaning
OFF	RED	OFF	Thermostat mode: Heating demand
OFF	GREEN	OFF	Thermostat mode: Cooling demand
YELLOW	RED	OFF	Manual mode: forced heating
YELLOW	GREEN	OFF	Manual mode: forced cooling
YELLOW	OFF	OFF	Manual mode: forced OFF
YELLOW/ OFF	GREEN/ RED/OFF	GREEN: Quick short blink	Communication between receiver and thermostat
YELLOW/ OFF	GREEN/ RED/OFF	GREEN: continuous	Receiver in radio configuration mode
OFF	OFF	GREEN: slow blink	There is no longer communication between the receiver and the thermostat both heating and cooling demand is stopped. A manual override is still possible (refer to "Manual control" on page 11).

#### Manual control

You can use the receiver to manually override the heating or cooling command of the thermostat when for example the batteries of the EKRTR are empty or when the thermostat is broken. Manual control is activated when the <sup>(3)</sup> LED lights up yellow. In thermostat mode the <sup>(3)</sup> LED is off.



## 4. Setting up codes in the installer menu

You can set up codes, starting from the time and date menu (in advanced mode).



As a consequence of a customized configuration, it is not abnormal that some codes are no longer accessible.

- 1 Activate the advanced mode by pushing ▷ during 5 seconds in OFF mode (他).
- 2 Navigate to the date and clock setting menu (B) by pressing .
- 3 Press > and keep it pressed while now pressing @ during 10 seconds.

is displayed next to \u004fr.



- 4 Press or ▶ to consult the current settings of the codes.
- 6 Press ( ) or ( ) to increase or decrease the code value by 1 step.

To put a code back to its default value, press 🗇 and 😑 at the same time.

7 Press (x/2) to save your selection.

You can exit this code menu by going to the "End" code and pressing  $\fbox{\ensuremath{\mathbb{R}}}$  .

Refer also to "Overview of all codes" on page 15.

#### 4.1. Set-up for heating/cooling applications

For heating/cooling applications, set the following codes:

1st code	2nd code	Description	Required setting
Sr	01	Cooling mode present?	462

#### 4.2. Set-up floor temperature protection

If EKRTETS is installed as floor temperature sensor it can be used to manage and thus protect the floor temperature. Refer to "Installation of EKRTETS as floor temperature sensor" on page 3. When this function is active the icon  $\int_{a}^{b}$  flashes below the ambient temperature.

1st code	2nd code	Description	Required setting	Step
Sr	02	External temperature sensor EKRTETS installed?	¥ES	—
ŀ	01	Enable floor high/low temperature limit?	965	—
	02	Lower limit of floor temperature	18.0 <sup>(a)</sup>	0.5°C
	03	Upper limit of floor temperature	35.0(a)	0.5°C

To enable floor protection, set the following codes:

(a) default value. Can be modified as preferred.



# 4.3. Set-up for EKRTETS as external ambient temperature sensor

EKRTETS can be used as external ambient temperature sensor to control the room temperature (instead of the temperature sensor inside the thermostat). In that case, install the external temperature sensor where you want to control the ambient temperature.

1st code	2nd code	Description	Required setting
Sr	02	External temperature sensor EKRTETS installed?	YES
δr	01	Selection of sensor for temperature control: use external ambient temperature sensor?	962

To enable the function, set the following codes:



This function cannot be combined with floor temperature protection.

#### 4.4. Overview of all codes

Following codes can be changed in the installer menu:

1st	2nd				
code	code	Description	Default	Range	Step
Reado	out cod	es			
Ψ.	01+71	Calibration of temperature sensor inside the thermostat. Actual temperature + offset are displayed. The symbol appears when the offset deviates from 0.	Offset = 0	Offset: −5°C~5°C	0.1°C
	02 + (j	Calibration of external temperature sensor. Actual temperature + offset are displayed. The symbol appears when the offset deviates from 0.	Offset = 0	Offset: -5°C~5°C	0.1°C
	03	Calibration of humidity sensor. Actual humidity + offset are displayed. The symbol appears when the offset deviates from 0.	Offset = 0	Offset: −10°C~10°C	1%

1st code	2nd code	Description	Default	Range	Step
Install	ation c	odes			
Sr	01	Cooling mode present?	no	YES/no	—
	02	External temperature sensor EKRTETS installed?	no	YES/no	_
	03	rfinit and (m) are displayed on the LCD. This code is used during the receiver- thermostat radio configuration. Refer to "Receiver- thermostat radio configuration" on page 9.	_		
Tempo	erature	control codes			
Бг	01	Selection of sensor for temperature control: use external ambient temperature sensor?	no	¥£5 (use external temperature sensor)/ no (use temperature sensor inside the thermostat)	

1st code	2nd code	Description	Default	Range	Step
Daikin param heatin	advizes eters. T g applic	s not to change b hey are set for an ation.	elow tempe i optimal us	erature control e of the floor of	ooling/
δr	02	Use proportional band control?	YES	¥£5 (proportional band)/no (hysteresis)	—
	03	Hysteresis value	00.5	0.5~02.0	0.1°C
	0Y + 🏶	Duration proportional band (heating).	020	0 10~060	1 min.
	05 + 🏽	Minimum "on" time (heat demand).	007	002~ Gr 04/2	1 min.
	06 + 🕷	Minimum delay between 2 heating cycles.	003	00 I~ &r 04/2	1 min.
	07+*	Duration proportional band (cooling).	020	0 10~060	1 min.
	08 + ≉	Minimum "on" time (cool demand).	007	002~ Gr 07/2	1 min.
	09 + *	Minimum delay between 2 cooling cycles.	003	00 l~6r 01/2	1 min.
	D	Value of proportional band.	02.0	0 1.0~04.0	0.1°C
	11	Compensating value.	00.0	00.0~08.0	0.1°C
	12	Upper setpoint limitation.	310	22.0~31.0	0.5°C
	13	Lower setpoint limitation.	04.0	04.0~20.0	0.5°C

1st code	2nd code	Description	Default	Range	Step
Floor	temper	ature limit			
ŀ	01	Enable floor high/low temperature limit?	no	9E5/no	—
	02	Lower limit of floor temperature.	18.0	05.0~Upper limit (ፑዐ3)	0.5°C
	03	Upper limit of floor temperature.	35.0	Lower limit (7r 02)~500	0.5°C
Scheo	dule tim	er codes			
8r		Enable cooling/ heating link for the user-defined schedules <i>U</i>   and <i>U</i> ? When enabled and a user- defined schedule is selected in the schedule timer setting menu: in heating mode, schedule <i>U</i>   will be active; in cooling mode, schedule <i>U</i> will be active.	no	YES/no	

1st code	2nd code	Description	Default	Range	Step
Misce	llaneou	is codes			
9r	01	Daylight saving time implementation.	¥ES	YES/no	-
	₽+*	Forced heating (installation check).	no	YES/no	_
	8+*	Forced cooling (installation check).	no	YES/no	—
	15 + rESEERLL	Reset all settings back to factory configuration. Press (mt) during 5 seconds. The complete LCD is shown to confirm all settings are reset.			

## 5. Technical characteristics

## 5.1. EKRTR - Thermostat

Temperature read out	Steps of 0.1°C
Operating temperature	0°C~50°C
Setpoint temperature range	$4^{\circ}C^{37^{\circ}C}$ in steps of $0.5^{\circ}C$
Electrical protection	Class II - IP30 (indoor use, polution degree 2)
Feeding and autonomy	3 alkaline batteries AA.LR6 1.5 V approximately 2 years (depending on usage conditions)

#### 5.2. EKRTR - Receiver

Operating temperature	0°C~50°C
Electrical protection	Class II - IP44 (indoor use, polution degree 2)
Power supply	1N~50 Hz 230 VAC
Radio frequency and receiving zone	433.92 MHz, <10 mW. Range of approximately 100 m in open space. Range of approximately 30 m in residential environment.
Output relays	Maximum load 100 mA - 230 VAC
Maximum fuse amp	3 A
Power consumption	15 W, maximum.

## 5.3. EKRTETS (optional)

External temperature	NTC 10K at 25°C/3 meter lead
sensor	

## NOTES

\*A0000000 \*4PW45518-1

Copyright © Daikin

## DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW45518-1